
Site Attenuation of Limited-Size Ground Planes for Vertical Polarisation

Wolfgang Müllner
Alexander Kriz

Vertical is Different - Vertical is Difficult

- Site performance in VP is generally worse than in HP
- Standards:
 - ◆ RE testing and NSA: HP + VP
 - ◆ Antenna calibration and CALTS validation: HP only
- Why?

Consequences of VP Imperfections

- RE testing uncertainty
- Antenna calibration
- Substitution measurements

⇒ HP procedures = VP procedures ?

We need a better understanding of VP wave propagation for:


- ◆ **higher accuracy in RE testing**
- ◆ **higher accuracy in NSA measurement**
- ◆ **higher accuracy in antenna calibration**

Our Investigations


- Simulation of finite GP with FDTD
- Comparison of results with NEC and measurements
- Definition of DSA for site performance
- Detailed investigation of
 - material below / beside the GP
 - SA measurement methods fixed/scanned height
 - influence of GP size
 - influence of test distance
 - influence of antenna volume

Antenna Above Ground Plane


HP




VP



Simulation of Ground Plane Induced Currents




Simulation Result: Ground Plane Induced Currents




Field Distribution at RX antenna (infinite GP)


HP




VP




Field Distribution at RX antenna (finite GP)



Influence on SA, RX antenna fixed height



Influence on SA, distance variations



Consequences

- VP procedures **1** HP procedures
- VP uncertainties >> HP uncertainties

- VP Site attenuation testing procedure
 - ◆ height of RX antenna off maximum: NO
 - ◆ height scan of RX antenna (= maximum): YES
 - ◆ result depends on the antenna type and size

Consequences Antenna Calibration

- Standard Site Method:
 - ◆ quality of site is largest uncertainty contribution
- Reference Antenna Method:
 - ◆ good for identical antennas only!
 - ◆ large errors possible - depending on the dimensions difference of the antennas

Relevance of Results

- RE testing, intercomparison of results
- Construction of sites
 - ◆ shape
 - ◆ antenna/EUT position
 - ◆ edge design
- Standardisation
- Uncertainty calculation in RE testing, SA measurement and antenna calibration